

Warning personnel of active Machine Containment System.

Machine Containment System Warning Light

The ControlMaster® Warning Light for Machine Containment System informs the remote loader operator where the scanner barrier is located within the production level so they do not breach the scanner with the machine.

In addition, it alerts personnel approaching the production level that a remote loader is actively operating within that level and not to disrupt the scanner barrier.


The lighting's enclosure is specifically designed to be bolted on the top of the scanner mount, and when the containment system has been set, it will activate three high-intensity, flashing red lights.

When the scanner barrier has been tripped, the warning enclosure will stop flashing, to indicate that the system operation has stopped.


Features

- Improves mining safety
- Know where the scanner barrier is located with visual alert
- Powder-coated steel enclosure
- Designed to withstand the elements
- 3x red ultra-bright flashing LEDs

Parts

 APN: 15074

WARNING LIGHT FOR HEAVY DUTY MACHINE CONTAINMENT SYSTEM



Reference: SBCM0820001



RCT
Head Office
Unit 1-5/511 Abernethy Rd
Kewdale WA 6105, Australia
sales@rct-global.com

Australia +61 8 9353 6577
Africa +27 83 292 4246
Canada +1 705 590 4001
Central Asia +7 910 411 1174
USA +1 801 938 9214
South America +56 3 5229 9409

Copyright © 2023 Remote Control Technologies Pty Ltd. Images for illustration purposes only. Discover more @ rct-global.com