

Referencia: SBCM0609062



RCT
Head Office
Unit 1-5/511 Abernethy Rd
Kewdale WA 6105, Australia
sales@rct-global.com

Australia +61 8 9353 6577
Africa +27 83 292 4246
Canada +1 705 590 4001
Central Asia +7 910 411 1174
USA +1 801 938 9214
South America +56 3 5229 9409

Copyright © 2023 Remote Control Technologies Pty Ltd. Images for illustration purposes only. Discover more @ rct-global.com

Programming, Testing & Service Training for Qualified Technicians

Product Skills Training Levels 4 & 5

These high level courses are only available to select overseas company service personnel and to local RCT employees. For local service personnel the qualification is only valid while they are an RCT employee.

Note: Companies within Australia are recommended to return and/or contact their closest RCT office to have their Control Master® equipment tested and repaired.

DESCRIPCIÓN

Level four and level five are interrelated courses. Technicians undertaking level four training must have suitable electrical or electronic qualifications and experience in order to undertake the course. Technicians undertaking level four training must also complete the level 5 course in order to graduate from the course.

LEVEL 4 - INTERNAL PROGRAMMING/TESTING PROCEDURES

Level four trains service technicians how to test the internal circuit components of the remote control systems for faults. The course covers every aspect of the remote control systems internal operations. The course is a pre-requisite to allow the service technician to successfully perform an internal remote hardware service or repair.

Course Includes:

- Theory and practical
- System components operating functions
- Testing Internal componentry
- Fault and repair reports

LEVEL 5 - INTERNAL SERVICING PROCEDURES

Referencia: SBCM0609062



RCT
Head Office
Unit 1-5/511 Abernethy Rd
Kewdale WA 6105, Australia
sales@rct-global.com

Australia +61 8 9353 6577
Africa +27 83 292 4246
Canada +1 705 590 4001
Central Asia +7 910 411 1174
USA +1 801 938 9214
South America +56 3 5229 9409

Copyright © 2023 Remote Control Technologies Pty Ltd. Images for illustration purposes only. Discover more @ rct-global.com

Level five trains service technicians how to service or repair the internal hardware of the remote control systems using the transmitter and receiver service kits. The course illustrates how to correctly remove and replace the internal circuit panels, wiring looms and socket components. Remote control system testing is also performed to ensure the remote controls are working correctly on completion of the service.

Course includes:

- Theory and practical
- Transmitter / receiver servicing
- Commissioning procedures

Each training course is delivered using oral and written presentations. All participants are assessed using theoretical and practical exams. All courses with the exception of levels four and five are conducted on site by RCT's nationally accredited Training officers.

PLEASE NOTE:

Course costs, booking dates and duration are dependent on customer and course content

Referencia: SBCM0609062



RCT
Head Office
Unit 1-5/511 Abernethy Rd
Kewdale WA 6105, Australia
sales@rct-global.com

Australia +61 8 9353 6577
Africa +27 83 292 4246
Canada +1 705 590 4001
Central Asia +7 910 411 1174
USA +1 801 938 9214
South America +56 3 5229 9409

Copyright © 2023 Remote Control Technologies Pty Ltd. Images for illustration purposes only. Discover more @ rct-global.com