

Reduce engine damage & maintenance

ADVANCED MANAGEMENT SYSTEM (SERIES 2)

The system has two stages of visual alarm to alert the operator. If the first stage warning continues with engine RPM limit. If the first stage warning continues with engine RPM limit, the system will automatically apply the engine RPM down and then will reset the system once engine RPM is back to normal level.

The system includes the following features:

ENGINE OVER RPM DETECTION

The system has a frequency of 10Hz when the engine reaches the RPM limit.

ENGINE OVER RPM WARNING

Activates the LCD display on the screen, red LEDs and a sound.

ENGINE OVER RPM BRAKING

Protects the engine from over speed by activating the OEM electronic braking system.

SYSTEM VIOLATION MONITORING

The system logs all events, data can be downloaded as required.

APPLICATIONS

Trucks - Dozers - Graders - Excavators - Haul trucks - Loaders

Features

- One central display
- Reduces engine damage & maintenance costs
- Violation monitoring helps to ensure machine correct operation
- Promotes better operating standards
- Event logging (logs last 500 events in a CSV format)
- Easy download
- Easy to use and maintain

By clicking Accept All Cookies, you agree to the storing of cookies on your device to enhance site navigation, analyze site usage, and assist in our marketing efforts. [Cookie Notice Link](#)

Cookies Settings

☒ Strictly Necessary Cookies

☐ Functional Cookies

☐ Targeting Cookies

☐ Social Media Cookies

Save Choices

Accept Only Necessary Cookies

Accept All Cookies

Reference: AMS100 Dozer



RCT
Head Office
Unit 1-5/511 Abernethy Rd
Kewdale WA 6105, Australia
sales@rct-global.com

Australia +61 8 9353 6577
Africa +27 83 292 4246
Canada +1 705 590 4001
Central Asia +7 910 411 1174
USA +1 801 938 9214
South America +56 22 4423 6600

APN: 1111
APN: 9887

AMS-100 ELECTRONIC INPUT / OUTPUT MODULE
AMS-100 VERSION 2 ELECTRONIC DISPLAY

By clicking Accept All Cookies, you agree to the storing of cookies on your device to enhance site navigation, analyze site usage, and assist in our marketing efforts. [Cookie Notice Link](#)

Cookies Settings

☒

Strictly Necessary Cookies

☐

Functional Cookies

☐

Targeting Cookies☐

Save Choices

Accept Only Necessary Cookies

Accept All Cookies

Reference: AMS100 Dozer



RCT
Head Office
Unit 1-5/511 Abernethy Rd
Kewdale WA 6105, Australia
sales@rct-global.com

Australia +61 8 9353 6577
Africa +27 83 292 4246
Canada +1 705 590 4001
Central Asia +7 910 411 1174
USA +1 801 938 9214
South America +56 22 4423 6600