

IMPROVE SAFETY, PRODUCTIVITY AND ELIMINATE DAMAGE

FORKLIFT LEVEL ASSIST

Even the best operators can make mistakes judging the tilt of their forks when entering or exiting pallets or stacking products.

The AusProTec™ Forklift Level Assist can combat this issue, regardless of the level of operator, by indicating the level of the forklift tines on a clear and easy-to-read display.

The main cause of product, rack and equipment damage is from forks being tilted at the wrong angle. If the forks are not level, drivers can spear product, damage racks or splinter pallets, especially if product is not stacked evenly which all results in costly damage. The Forklift Level Assist is a solution that will quickly pay for itself by reducing these damages.

Available in counterbalance or reach truck models. Extreme condition models available upon request.

Caractéristiques

- Easy to install Less than 1 minute
- Accurate within 0.25 of one degree
- Environmentally sealed IP67 rated with CE Certification
- Adapts to bent or uneven forks
- Not permanently fixed to the forklift mast No drilling required
- Motion activated No on / off switch
- Easy-to-read display



Specifications:

Certifications	CE, ISO 9000/9001
Rating	IP67 rated
Working Temperature	-40 to 120 degrees F
Batteries	Uses 2 x "D" size Batteries – 12 to 18 month battery life
Accuracy	Accurate to 0.25 of one degree
Warranty	2 years

Las

Pièces

■ APN: 16717 SINGLE UNIT LEVEL ASSIST – COUNTER BALANCED OPTION

Reference: SBAP1021001



RCT Head Office

Unit 1-5/511 Abernethy Rd Kewdale WA 6105, Australia

sales@rct-global.com

Australia +61 8 9353 6577 Africa +27 83 292 4246 Canada +1 705 590 4001 Central Asia +7 910 411 1174 USA +1 801 938 9214 South America +56 3 5229 9409

 $Copyright @\ 2023\ Remote\ Control\ Technologies\ Pty\ Ltd.\ Images\ for\ illustration\ purposes\ only.\ Discover\ more\ @\ rct-global.com$