

IMPROVE SAFETY, PRODUCTIVITY AND ELIMINATE DAMAGE

FORKLIFT LEVEL ASSIST

Even the best operators can make mistakes judging the tilt of their forks when entering or exiting pallets or stacking products.

The AusProTec™ Forklift Level Assist can combat this issue, regardless of the level of operator, by indicating the level of the forklift tines on a clear and easy-to-read display.

The main cause of product, rack and equipment damage is from forks being tilted at the wrong angle. If the forks are not level, drivers can spear product, damage racks or splinter pallets, especially if product is not stacked evenly which all results in costly damage. The Forklift Level Assist is a solution that will quickly pay for itself by reducing these damages.

Available in counterbalance or reach truck models. Extreme condition models available upon request.

Features

- Easy to install – Less than 1 minute
- Accurate within 0.25 of one degree
- Environmentally sealed – IP67 rated with CE Certification
- Adapts to bent or uneven forks
- Not permanently fixed to the forklift mast – No drilling required
- Motion activated – No on / off switch
- Easy-to-read display

Parts

APN: 16717

SINGLE UNIT LEVEL ASSIST – COUNTERBALANCED OPTION

APN: 16718

DUAL UNIT LEVEL ASSIST – REACH / TELEHANDLER OPTION



Specifications:

Certifications	CE, ISO 9000/9001
Rating	IP67 rated
Working Temperature	-40 to 120 degrees F
Batteries	Uses 2 x "D" size Batteries – 12 to 18 month battery life
Accuracy	Accurate to 0.25 of one degree
Warranty	2 years

Reference: SBAP1021001



RCT
Head Office
Unit 1-5/511 Abernethy Rd
Kewdale WA 6105, Australia
sales@rct-global.com

Australia +61 8 9353 6577
Africa +27 83 292 4246
Canada +1 705 590 4001
Central Asia +7 910 411 1174
USA +1 801 938 9214
South America +56 3 5229 9409