

Increase productivity and stop overcranking damage

OVERCRANK PROTECTION

If a machine's engine is cranked (turned or wound over) and fails to start, the continued cranking of the engine results in excessive heat and load on the starting circuit. This results in damage or premature failure of batteries, starter motors and cabling. This decreases the life of the machine's starting circuits which in turn reduces machine availability and productivity.

The Muirhead® Overcrank Protection kit preserves the starting system by preventing crank when the engine is turned on and limiting the amount of times the engine may be cranked; then locking out the start circuit to allow for system components to cool down. This reduces the flattening of batteries and abuse of an engine's starting components – helping to extend the life of the system as a whole.

The Overcrank Protection system will provide a visual indication to the operator – alerting them when a starting circuit is isolated. An override switch may be incorporated to allow maintenance staff to carry out servicing tasks without the start circuit being inhibited.

Basic on-machine configuration of both the crank time and start interlock periods, or advanced programming are available through a PC using the Muirhead® Programmable Controller Utility (PCU) software package.



Caractéristiques

- Multi-voltage
- Universal application
- Visual warning
- Integrated mount
- Simple on-machine time period adjustment
- Advanced configuration via the Muirhead® Programmable Controller Utility
- Optional Crank lockout when engine already running

Specifications

System Voltage	12 to 24 VDC (reverse polarity protected)
Maximum Current Output	10Amp Continuous
Environmental Rating	IP 65
Inputs	Digital / Analogue
Outputs	Digital
Operating Temperature	-10°C to 65°C (14°F to 149°F)
Dimensions	199mm (L) x 80mm (W) x 65mm (H) (7.83" x 3.14" x 2.55")

Pièces

- APN: 11966 CONTROLLER OVERCRANK MODULE MULTI VOLTAGE
- APN: 12725 KIT OVERCRANK 24V
- APN: 12726 KIT OVERCRANK 12V

Reference: SBMH050717



RCT
Head Office
Unit 1-5/511 Abernethy Rd
Kewdale WA 6105, Australia
sales@rct-global.com

Australia +61 8 9353 6577
Africa +27 83 292 4246
Canada +1 705 590 4001
Central Asia +7 910 411 1174
USA +1 801 938 9214
South America +56 3 5229 9409