



Prevent accidental drive offs

FUEL CAP ISOLATION SYSTEM

The Muirhead® Fuel Cap Isolation system has been designed to prevent the machine operator from starting the machine and driving away with the fuel filler still attached. This will eliminate damage to machines, refuelling stations, hoses and prevent hazardous fuel spills.




The system inhibits the operator from starting the machine, without firstly ensuring the fuel cap has been placed securely back onto the quick fill adaptor on the fuel tank.

The Muirhead® Fuel Cap Isolation system has an intrinsically safe circuit design with safety certification (inductive sensor) for the fuel cap component to be fitted in a zone 0 hazardous area.

Features

- Intrinsically safe circuit design
- High quality connectors and wiring components
- Water and vibration resistant
- Safety certificate for the fuel cap (inductive sensor) to be used in a zone 0 hazardous area
- Prevents damage to the refuelling station
- Reduces refuelling accidents
- Reduces contaminants entering tank
- Maintenance free operation
- Easy to install
- In dash visual indication

Parts

- | | |
|---|--|
|  APN: 7808 | FUEL CAP ISOLATION CONTROLLER TO SUIT 7811 |
|  APN: 7809 | REPLACEMENT FUEL CAP TO SUIT 7811 |
|  APN: 7811 | FUEL CAP ISOLATION SYSTEM |



Reference: SBMH0909073



RCT
Head Office
Unit 1-5/511 Abernethy Rd
Kewdale WA 6105, Australia
sales@rct-global.com

Australia +61 8 9353 6577
Africa +27 83 292 4246
Canada +1 705 590 4001
Central Asia +7 910 411 1174
USA +1 801 938 9214
South America +56 22 4423 6600

Copyright © 2023 Remote Control Technologies Pty Ltd. Images for illustration purposes only. Discover more @ rct-global.com